

Temescal

Electron Beam Power Supplies Models CV-14 and CV 14 A and B

(CV-14: 0407-4340-1-9; 0411-8260-1-9)

(CV-14 A: 0506-2810)

(CV-14 B: 0506-2920)



Temescal, an operating unit of
Edwards High Vacuum International, a division of The BOC Group, Inc.
2850 Seventh Street, Berkeley, CA 94710: Telephone: 415-841-5720; FAX: 415-548-8108

CONTENTS

- Terms and Conditions
- User Responsibility
- SAFETY
- Health Hazard
- List of Illustrations
- List of Reference Drawings

- 1 SPECIFICATIONS
- 1.1 Introduction
- 1.2 High Power Distribution
- 1.3 High Voltage Control
- 1.4 Electron Gun Control
- 1.4.1 High Voltage Vacuum Relays
- 1.5 Beam Position Control (Standard)
- 1.6 Beam Position Sweep Control (Optional)

- 1.7 Physical Specifications
- 1.7.1 Weight
- 1.7.2 Dimensions
- 1.8 Electrical Specifications
- 1.8.1 Input Power
- 1.8.2 Electrical Outputs
- 1.8.3 Control Input
- 1.9 Cables

- 1.10 Support Facilities
- 1.10.1 Cooling Water
- 1.10.2 Cooling Air

- 2 INSTALLATION
- 2.1 General Information
- 2.2 Mechanical Installation
- 2.2.1 Interlock Cable Terminal Strip(s)
- 2.2.2 Power Supply Cooling Water Connections
- 2.2.3 External Interlock Installation
- 2.3 Electrical Connections
- 2.3.1 System Ground
- 2.3.2 Utility Power
- 2.3.3 Vacuum Tank Electron Beam Gun Wiring
- 2.3.4 Power Supply To Vacuum Tank Connections
- 2.3.5 Rate Monitor Input (CV-14 A and B)
- 2.3.6 Power Supply to Vacuum Tank Connections
- 2.3.7 Rate Monitor Input (Original CV-14)
- 2.3.8 Interconnecting Cables
- 2.3.9 Solenoid Valve (Tube Cooling Water)
- 2.3.10 Grounding Hooks

- 3 CONTROLS AND OPERATION
- 3.1 Front Panel Controls And Indicators
- 3.1.1 Power Supply Module
- 3.1.2 Control Module
- 3.1.3 Auxiliary Controls

Temescal CV-14 A and B

- 3.2 Initial Operation
 - 3.2.1 Preliminary Precautions
 - 3.2.2 Preliminary Control Settings
 - 3.2.3 Initial Turn-On
 - 3.2.4 External Interlock Check
- 3.3 Normal Operation
 - 3.3.1 Precautions
 - 3.3.2 Normal Operating Procedure

- 4 THEORY OF OPERATION
 - 4.1 Overall System
 - 4.2 High Voltage Section, Detailed Circuit Analysis
 - 4.2.1 High Voltage Power Supply
 - 4.2.2 High Voltage Relays
 - 4.2.3 Triode Cathode Bias Network and High Voltage Regulator
 - 4.2.4 High Voltage Regulation
 - 4.2.5 High Voltage Dividers

 - 4.3 Electron Gun Controller
 - 4.3.1 Overall Operation
 - 4.3.2 Transducer Current Sensing
 - 4.3.3 Emission Control
 - 4.4 Beam Position (Focus) Circuits
 - 4.4.1 Longitudinal Beam Position Focus Control
 - 4.4.2 Beam Position Focus Interlock (Electromagnetic Focus Guns Only)

 - 4.5 Sweep Circuits (Optional)
 - 4.5.1 Lateral Sweep Output
 - 4.5.2 Longitudinal Sweep Output
 - 4.6 Primary Power
 - 4.6.1 High Voltage Step-Start
 - 4.6.2 Electron Gun Control Primary Power

- 5 MAINTENANCE
 - 5.1 Preventive Maintenance
 - 5.1.1 Voltage Changeover
 - 5.2 Service Adjustments
 - 5.2.1 Power Supply Adjustments
 - 5.2.2 Electron Gun Control Adjustments
 - 5.2.3 Beam Position Control Adjustments
 - 5.2.4 Sweep Adjustments

 - 5.3 Subassemblies, General Description By Section Number
 - 5.4 General Troubleshooting Information
 - 5.5 Troubleshooting Chart, Major Circuits
 - 5.5.1 High Voltage Control Troubles
 - 5.5.2 Emission Control Troubles
 - 5.5.3 Beam Position (Focus) Troubles
 - 5.5.4 Sweep Troubles

Temescal CV-14 A and B

- 6 PARTS LISTS
- 6.1 Recommended Spare Parts
- 6.2 Assembly Spares
 - 6.2.1 Service Panel, Section 100
 - 6.2.2 Main Circuit Breaker and Step-Start Assembly,
Section 200, 400
 - 6.2.3 Control Transformer Assembly, Section 300
 - 6.2.4 High Voltage Transformer Assembly, Section 500
 - 6.2.5 High Voltage Rectifier Assembly, Section 600

